
## **INSTALLATION**

4. Insert the embedding box into the cavity and fix it, then perform the wires connectiong and test the system working, after that attach back the front panel onto the embedding box, fix the front panel by the two allen-screws, finally place the two screw hole covers to finish the installation.









CONNECT THE CABLE AND INSTALL THE PANEL ONTO THE EMBEDDING BOX, FIX THE PANEL BY THE TWO ALLEN-SCREWS FINALLY PLACE THE SCREW COVERS

## **WIRING DIAGRAM**



## INTERFACE INTRODUCTION





## AD-K101 USER'S MANUAL





Thank You For Choosing Our Products Date of Purchasing: